### PowerStore 128K x 8 nvSRAM

#### **Features**

- ☐ High-performance CMOS non-
- 25 ns Access Time
- $\sqcap$  I<sub>CC</sub> = 15 mA at 200 ns Cycle Time
- ☐ Automatic STORE to EEPROM on Power Down
- Hardware or Software initiated STORE (t<sub>STORE</sub> < 10 ms)
- ☐ Automatic STORE Timing
- ☐ 10<sup>6</sup> STORE cycles to EEPROM ■ 100 years data retention in **EEPROM**
- ☐ Automatic RECALL on Power Up
- Software RECALL Initiation  $(t_{RECALL} < 20 \mu s)$
- ☐ Unlimited RECALL cycles from **EEPROM**
- Single 5 V ± 10 % Operation
- Operating temperature ranges 0 to 70 °C

-40 to 85 °C

- ☐ CECC 90000 Quality Standard
- ☐ ESD protection > 2000 V (MIL STD 883C M3015.7)
- ☐ Packages: SOP32 (450 mil) PDIP32 (600 mil)

### Description

The U632H1708 has two separate volatile static RAM 1024x1024 bits modes of operation: SRAM mode and nonvolatile mode. In SRAM □ 10 ns Output Enable Access Times mode, the memory operates as an ordinary static RAM. In nonvolatile ☐ Unlimited Read and Write to SRAM operation, data is transferred in parallel from SRAM to EEPROM or from EEPROM to SRAM. In this mode SRAM functions are disab-

The U632H1708 is a fast static RAM (25 ns), with a nonvolatile electrically **PROM** erasable (EEPROM) element incorporated in each static memory cell. The SRAM can be read and written an unlimited number of times, while independent nonvolatile data resides in EEPROM.

Data transfers from the SRAM to the EEPROM (the STORE operation) take place automatically upon power down using charge stored in an external 100 µF capacitor. Transfers from the EEPROM to the SRAM (the RECALL operation) take place automatically on

power up. The U632H1708 combines the high performance and ease of use of a fast SRAM with nonvolatile data integrity.

STORE cycles also may be initiated under user control via a software sequence or via a single pin (HSB). Once a STORE cycle is initiated. further input or output are disabled until the cycle is completed.


Because a sequence of addresses is used for STORE initiation, it is important that no other read or write accesses intervene in the sequence or the sequence will be aborted.

RECALL cycles may also be initiated by a software sequence.

Internally, RECALL is a two step procedure. First, the SRAM data is cleared and second, the nonvolatile information is transferred into the SRAM cells.


The RECALL operation in no way alters the data in the EEPROM cells. The nonvolatile data can be recalled an unlimited number of times.

# Pin Configuration



Signal Name	Signal Description
A0 - A16	Address Inputs
DQ0 - DQ7	Data In/Out
Ē	Chip Enable
G	Output Enable
W	Write Enable
VCCX	Power Supply Voltage
VSS	Ground
VCAP	Capacitor
HSB	Hardware Store/Busy

# Logic Block Diagram





#### LIFE SUPPORT POLICY

ZMD products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the ZMD product could create a situation where personal injury or death may occur. Components used in life-support devices or systems must be expressly authorized by ZMD for such purpose.

#### LIMITED WARRANTY

The information in this document has been carefully checked and is believed to be reliable. However Zentrum Mikroelektronik Dresden GmbH (ZMD) makes no guarantee or warranty concerning the accuracy of said information and shall not be responsible for any loss or damage of whatever nature resulting from the use of, or reliance upon it. The information in this document describes the type of component and shall not be considered as assured characteristics.

ZMD does not guarantee that the use of any information contained herein will not infringe upon the patent, trademark, copyright, mask work right or other rights of third parties, and no patent or licence is implied hereby. This document does not in any way extent ZMD's warranty on any product beyond that set forth in its standard terms and conditions of sale.

ZMD reserves terms of delivery and reserves the right to make changes in the products or specifications, or both, presented in this publication at any time and without notice.