MODEL C TRANSDUCER Data Sheet

The Model C Tension Transducer is a strain-gauge tensionsensing device designed for versatility, accuracy, reliability, easy maintenance and quick trouble-free installation. It is the most technically advanced and robust shaft-mount tension transducer available.

BENEFITS/FEATURES

- Measures actual web tension. Eliminates guess work and allows running correct tension consistently.
- Helps reduce or eliminate web breakage, stretching, registration and length problems by making it possible to control tension accurately.
- Sealed from dust and moisture: seals are recessed. blocking access from potential damage.
- Dual cantilever beam provides high strength and accuracy even at low tension.
- Temperature compensated for stable output.
- Grease fitting for quick re-lubrication without disassembly or removal from machine (L version only).
- Stainless steel and aluminum construction for excellent corrosion resistance.
- All mounting styles can be rotated to any position for precise orientation except the PB style which can be rotated in 45° increments.

- Environmental Connector (EC) Seals with mating cable electrical connector to protect against contact oxidation; especially useful in corrosive environments.
- Extended Range Output (XR) Extra sensitive to low tensions. XR produces twice the output signal for a given load rating. This increases the signal to noise ratio. It is used in applications requiring a full scale tension force that is as low as 6% of the transducer load rating. 12% is standard. Extended range (XRE) is required for the mating electronic unit.
- Full Bridge (FB) Four strain gauges instead of two to form a full Wheatstone Bridge connection. See Note 6.
- Labyrinth Seal (LS) A non-contact seal used for minimal drag for very low break-away torque. Used on Live shaft only. Size 0,1:Typ.0.3 oz-in. Size 2: 0.6 oz-in.
- Metric Mounting Stud (MMS) Metric mounting screw for S type transducers.

Available Mounting Styles







C2LS Screw Mount

C2DFL Flange Mount

C1DPB Pillow Block Mount



Through-Frame Mount



Piloted Flange Mount

- Built-in compensation for changes in idler shaft length caused by temperature changes and deflection.
- Idler shaft can be removed from transducer without removing transducer from machine on the live (L) Split-Cap and dead (D) shaft version.
- No Cap (NCP) Live shaft transducer coupling with no clamp cap. Ensures a spin-centered installation of rotating shafts.
- Piloted Flange (PFL) Mounting Style in which transducer has a piloted mounting flange that fits directly in place of industry standard RFC style 3.0" piloted flange bearings.
- Through-Frame (TF) Mounting style in which a Model C2D with rear connector fits into a recessed 72mm hole in machine frame. Saves space, and allows longer idler roll shaft.
- Vacuum Compensation (VAC) Special features for fast and complete air evacuation. Used for transducers installed in vacuum metalizers. Consult factory.

DIRECTION

PRODUCT CODE

You may order by description or by specifying the code by matching each labeled place with one of the choices below.

EC.XR **EXAMPLE**: SIZE MOUNTING FORCE OPTIONS **TYPE** LOAD SHAFT CONNECTOR **RATING**

STYLE

SIZE	TYPE	MOUNTING STYLE	LOAD RATING	_		SIZE 2 SIZE 2 Live		CONNECTOR POSITION ⁴	FORCE DIRECTION ⁷	OPTIONS		
	D = Dead L = Live	S = Screw / Bolt ³ PB = Pillow Block FL = Flange	10 lbs. ¹ 25 lbs. 50 lbs. 100 lbs. 150 lbs. ¹ 200 lbs. ² 400 lbs. ² 800 lbs. ²	1/2" 5/8" 3/4" 1 1/8 1 1/4 1 1/2 20mm 25mm 30mm	1/2 5/8 3/4 7/8 1 20mm 25mm	3/4 7/8 1 1 1/8 1 3/16 1 1/4 1 1/2 1 3/4 25mm 30mm 40mm	3/4 7/8 1 1 1/8 1 1/4 1 1/2 25mm 30mm 40mm	12 (12:00) 1:30 3:00 4:30 6 (6:00) Std. S, FL only 7:30 9:00 10:30 Rear (Std. PB only)	12 (12.00) 1:30 3:00 4:30 6 (6:00) 7:30 9:00 10:30	EC = Environmental Connector XR = Extended Range ⁵ FB = Full Bridge ⁶ LS = Labyrinth Seal MMS = Metric Mounting Stud NCP = No Cap Live Shaft Coupling PFL = Piloted Flange Mounting Style TF = Through-Frame Mounting Style VAC = Vacuum Compensation Z = Special (SPR)		

BUSHING

- 1. Available on Size 0, 1 only.
- 2. Available on Size 2 only.
- 3. Standard mounting bolt for S and FL styles is in inches. Standard Taps for the S style are: Size 0 = 3/8 -16, M10,

Size 1 = 1/2 - 13, M12

Size 2 = 5/8 - 11, M16

- 4. Connector position is figured relative to force direction for S and FL mounting styles and assumes force is at 6:00 o'clock. For PB mounting style, if the connector is not at rear, then the mount surface is considered the 6:00 o'clock position for force direction.
- 5. Requires that indicator/controller has XRE option.
- 6. Applies only if one transducer is used.

POSITION

7. For PB style only.

SPECIFICATIONS:

ELECTRICAL

Excitation: 5 Vdc, regulated (10Vdc with XR) Output: 250mVdc, nominal, at 5V excitation (500mV at 10V excitation with XR)

Strain Gage Resistance: 100 ohms, nominal Non-Repeatability: ±1/4% Full Span (FS)

Combined Non-Linearity and Hysteresis: ±1/2% (FS) Temperature range: -10°F to 200°F (-23°F to 93°C) Temperature Coefficient: 0.02% FS per °F, typical

(0.036% FS per °C) **Mating Electrical Connector:** Amphenol MS3106A-10SL-3S

Connector Pin Assignment: A = transducer output;

B = + 5VC = -5V

MECHANICAL

Overload Capacity: Size 0,1 = 1200 lbs. (5338 N),

Size 2 = 2500 lbs. (11,121 N),

Deflection of Sensor Beam: 0.005 in. max. (.127 mm)

Material: 6061, 7075-T6 Aluminum; 303, 304 Stainless Steel **Connector Position (standard):**

> Screw, Flange, and Piloted Flange mount = 6 o'clock (connector points in tension force direction) Pillow Block and Through Frame = center rear

Shaft Bushings (max.):

Size 0,1 Dead = 1.5" (30mm) Live = 1" (20mm) Size 2 Dead = 1.75" (40mm) Live = 1.5" (40mm)

Basic Dynamic Load Rating of Bearings:

Size 0.1: 1,990 LBF (8,840 N) Size 2: 3,510 LBF (15,600 N)

SELECTION OF LOAD RATING

The correct transducer load rating for your application is determined by maximum web tension, wrap angle, and roll weight. Choose the appropriate wrap configuration from the diagrams below. Then compute the Net Force using the formula below the diagram. (The direction of the tension force determines which diagram and formula to use).

The selected load rating, may be 20% less than the computed Net Force. The actual force on the transducer will read 125% of the load rating before hitting the stops. This is acceptable because the Net Force formula contains an oversizing factor of 2, which means that the actual force exerted on the transducer will not exceed its rating. Sometimes, a roll is so heavy that its weight uses up most of the operating range of the transducer. When this happens, it may not be possible to adjust the tension indicating meter to read zero when tension is zero


because the adjustment range of the electronic circuit has been exceeded. To find out if the roll is too heavy. compare the load rating with the effective weight of the roll as follows: The effective roll weight is the "WCOS(A)" term in the formula. If WCOS(A) is more than 95% of the load rating chosen, the tension meter will probably not be adjustable to zero. If this is the case, one or more of the following changes must be made to reduce WCOS(A) to less than 95% of the load rating:

- 1. Reduce the transducer roll weight
- Increase angle (A)
- Use the next higher load rating (This is the least desirable choice because it reduces transducer signal output).


WRAP 1

WRAP 2

Tension Force F_T, **above** horizontal Tension Force F_T, **below** horizontal








$$\frac{\text{NET}}{\text{FORCE}} = \frac{4\text{T SIN} \left(\frac{B}{2}\right) + \text{W COS(A)}}{2}$$

WRAP 3

Tension Force F_T, is horizontal



NET FORCE =	4T SIN $\left(\frac{B}{2}\right)$
FURUE	

TABLE 1 Angle (Degrees) SINE COSINE 1.000 0 .000 5 .087 .996 10 .985 .174 15 .259 .966 20 .342 .940 .906 25 .423 30 .500 .866 35 .574 .819 .766 40 .643 45 .707 .707 50 .766 .643 55 .819 .574 60 .500 .866 65 .906 .423 70 .940 .342 75 .259 .966 80 .985 .174 85 .996 .087 1.000 .000

W = idler roll weight, T = Maximum web tension, B = Wrap angle = 180° - C° , A = Angle between Tension Force F_{τ} and vertical

Note: These sizing formulas contain an oversizing factor of 2X tension for tension surges.


DIMENSIONS


SIZE		A (D) ¹	A (L) ¹	В	С	D	Е	F (max)	G	H (max)	J	K (max)	L	М	N
0	in.	1.50	1.00	0.13	1.80	3/8 - 16	1.04	3.02	0.95	2.45	2.75	1.62	0.56	3.12	0.34
	mm	30	25	3.30	45.7	M10 x 1.5	26.4	76.7	24.1	62.2	69.9	41.4	14.2	79.2	8.6
1	in.	1.50	1.00	0.13	1.80	1/2 - 13	1.04	3.18	0.95	2.61	2.55	1.71	0.56	4.00	0.43
	mm	30	25	3.30	45.7	M12 x 1.75	26.4	8.08	24.1	66.3	64.8	43.4	14.2	101.6	10.9
	in.	1.75	1.50	0.21	2.60	5/8 - 11	1.04	4.00	1.15	3.00	3.99	2.16	0.98	4.49	0.53
	mm	40	40	13	66	M16 x 2	26.4	101.6	29.2	76.2	101.3	54.9	24.9	114	13.5

Notes: 1: Bushings are available for smaller shaft diameters. D is for Dead shaft version, L is for Live Shaft version.

SIZE		Р	Q	R	S (L)	S (D)	Т	U	V	W	X	Υ	Z	AA
0	in.	2.50	0.43	0.81	2.26	2.26	0.37	3.00	1.37	1.37	0.38	3.25	4.25	2.66
	mm	63.5	10.9	20.6	57.4	57.4	9.4	76.2	34.8	34.8	9.7	82.6	108	67.6
1	in.	3.25	0.53	0.72	2.26	2.26	0.53	3.00	1.41	1.63	0.38	4.00	5.38	2.66
	mm	82.6	13.5	18.3	57.4	57.4	13.5	76.2	35.8	41.4	9.7	101.6	136.7	67.6
2	in.	3.50	0.53	0.87	3.38	3.11	0.50	4.00	1.74	2.06	0.63	5.00	6.00	3.52
	mm	88.9	13.5	22.1	85.9	79	12.7	101.6	44.2	52.3	0.16	127	152	89.4

LIVE SHAFT "L" TAPERED COUPLING SHOWN









FL style conversion flanges are available to adapt the Model C to installations designed for the old DFE model 3.22 and 2.25 transducers.

FLANGE (FL) MOUNTING STYLE (Option) DEAD SHAFT "D" SPLIT COUPLING SHOWN






PILLOW BLOCK BRACKET (PB) MOUNTING STYLE (Option)


inches (mm)

DEAD SHAFT "D" SPLIT COUPLING SHOWN



THROUGH-FRAME (TF) MOUNTING STYLE (Option) Size 2 Only

LIVE SHAFT "L" TAPERED COUPLING SHOWN



PILOTED FLANGE (PFL) MOUNTING STYLE (Option) (Replaces industry standard RFC style bearings)

