

#### **DATA SHEET**

**DN520-40** 

#### SUBMINATURE PROPORTIONALLY CONTROLLED A.C. HEATER


# HEATER BLOCK DIAGRAM

#### **GENERAL DESCRIPTION**

The DN520-40 is a subminiature proportionally controlled 115Volt A.C heater, whose temperature can be programmed with a single external resistor. This device is ideally suited for regulating the temperature of sensitive electronic components such as fiber optic components and crystal oscillators. The DN520-40 is in a ceramic package and can supply up to 32 watts of power from an unregulated power supply.

#### **FEATURES**

- BERYLLIA BASE FOR GOOD THERMAL CONDUCTION
- REGULATION TEMPERATURE FROM 40°C TO 100°C
- 115 VOLT A.C. OPERATION
- · ELECTRICALLY ISOLATED FROM THE CASE




#### **MAXIMUM RATINGS**

Rating	Symbol	Value	Unit
Supply Voltage	Vs	125	Vac
Power Dissipation	Рв	60	Watts
Operating Temperature	Тмах	120	°C
Storage Temperature	TMIN	- 65 to +150	°C

#### **OPERATING CHARACTERISTICS**


Characteristic	Symbol	Min	Max	Unit
Supply Voltage (Pin 1 to Pin 2)	Vs	100	125	Vac
Turn On Current Range at Vs = 115 Vac	ls	0.250	0.300	AAC
Steady State Supply Current  @ Vs = 115 VAC	ls	0.008	0.440	Aac
Temperature Variation over Operating Voltage	ΔΤν		2	°C
Temperature Variation with Load	ΔTL		10	°C
Control Temperature Range	Tc	Ta + 5	100	°C
Control Resistor Value Pin 3 to Pin 4 (See Figure 1)	R	0		Ω
Maximum Control Temperature when Rc = 0	Тмах		120	°C
Operating frequency range	fo	45	420	Hz






## Heater Temperature vs Temperature Set Resistor


# MAX. START UP CURRENT VS.



# MAX. THERMAL POWER AVAILABLE VS. SUPPLY VOLTAGE




#### TYPICAL BASE TEMPERATURE CHANGE WITH POWER DISSIPATION



The base material of the DN520-40 is Beryllia which provides efficient energy transfer from the heating element located inside the heater and the heating surface of the the DN520-40. The temperature drop across the Beryllia substrate, as a function of power transfer, is shown in figure 3.

The thermal interface between the DN520-40 heater and the device being heated causes a temperature drop. Care should be taken to make sure that a good thermal interface exists between the two surfaces.



### NOTES:

- 1. The DN520-40 heaters are tested for gross leaks in Fluorocarbon at 125°C.
- 2. Optimum heat transfer between the DN520-40 and the device being heated occurs when a thermal compound, such as Dow Corning 340, is applied to the mounting surface of the heater.