

OZ OPTICS LTD.

219 WESTBROOK RD, CARP, ON, CANADA, K0A 1L0 TEL:(613) 831-0981 FAX:(613) 836-5089 E-MAIL: sales@ozoptics.com WEB SITE: www.ozoptics.com

LASER TO FIBER COUPLERS WITH ATTENUATOR OR SHUTTER

FEATURES:

- High Power HandlingHigh Resolution
- Polarization Insensitive Attenuator/Shutter
- Wide Attenuation Range
- Manual and Electrically Controlled Versions
- Different Connector Réceptacles

APPLICATIONS:

- Power Setting
- Safety Interlocks
- Colour Balancing
- Spectroscopy
- Medical, Pharmaceutical, and Chemical Sensors
- Interferometric Sensors
- OEM Laser SystemsLaser Shows/Entertainment

SPECIFICATIONS:

 Coupling Efficiency: Typically >55% for singlemode and

polarization maintaining fibers, >80% for multimode fibers

· Backreflection: -14dB for receptacle style couplers using

flat finish connectors

-60dB for receptacle style couplers using

angle finish connectors

 -25dB for LPSC-01 style pigtailed source couplers

-40dB or -60dB for LPSC-03 style pigtailed

source couplers

Polarization Extinction Ratio: >20dB

25dB, 30 dB version are also available

 Available Wavelengths: 180 - 2000nm


Power Handling: Up to 3 Watts for singlemode applications

Over 100 Watts for multimode applications

Attenuation Range: 0 to 60dB · Resolution: 0.05dB

Manual/Current Drive/RS-232/SPI/I2C • Interface:

LASER TO FIBER COUPLER WITH ELECTRICALLY **CONTROLLED ATTENUATOR**



PRODUCT DESCRIPTION:

OZ Optics offers source to fiber couplers with built in attenuators or shutters. These couplers provide a precise method to control the intensity of light through a fiber. They are available in both receptacle style and pigtail style.


Source couplers are available with both manual and electrically controlled attenuators. In the manual version, the beam from the laser is partially blocked by a precision blocking screw. Adjusting the screw controls how much light reaches the fiber. In the electrically controlled version, a stepper motor controls the amount of attenuation. It includes a homing sensor to calibrate the attenuator against.

The stepper motor is available with several options for control. The basic model provides direct access to the motor as well as logic level output for the HOME sensor. The -DR option adds a high speed driver circuit that accepts four logic level signals to control the motor. Finally, the -MC option features an embedded microcontroller. These units are addressable and accept RS232, SPI, and I2C protocols.

The shutter accepts a +12V supply to block or transmit the beam. This shutter is normally closed until voltage is applied. This makes it ideal for safety interlocks. A manual switch is also on the shutter. The shutter response speed is under 20 milliseconds. Shutters with foot pedal control are also available.

OZ Optics can also provide shutters with a safety interlock function on the fiber connection. If the fiber is disconnected from the coupler, the shutter will close automatically. Contact OZ Optics for more information.

09/99 OZ Optics reserves the right to change any specifications without prior notice.



To determine the best laser to fiber source coupler for your application please complete a Laser to Fiber Delivery System Questionnaire. OZ Optics will then recommend a coupler based on your response.

Unit prices range from \$350USD to \$1000USD for standard applications with delivery being between 4 and 8 weeks after receiving your order. Quantity discounting and blanket orders can be arranged. Contact OZ for more information.