Field^{IT}

2600T Series Pressure Transmitters

Models S264 Remote Seals

■ Wide range of remote seal types

- allow optimum design for each application without compromise of performance

Large selection of options, materials and fill fluids

- meet nearly all process requirements

All welded constructions

 combine an economically feasible and technically sound solution ensuring total reliability at line pressure down to full vacuum

Special designed remote seals for individual process solutions

- add flexibility for most demanding services



ABB 2600T Series Engineered solutions for all applications



Remote Seals Overview

The S26 seals are used in combination with 2600T transmitters, allowing differential, gauge or absolute pressure measurements. Connection of the seal(s) to the relevant transmitter can be achieved as follows:

- directly mounted with a short capillary connecting the "integral" seal to the transmitter sensor;
- through a capillary system which link the transmitter sensor to a "remote" seal of any version.

Using remote seal the transmitter can be selected with

- two seals using same fill fluid, capillary and diaphragm size
- one seal having the other side configured with a process flange for wet/dry leg connection or a blind flange providing vacuum or atmospheric reference.

Model 264HR/NR transmitters have always one remote seal only, with a selectable reference to atmosphere or vacuum respectively for gauge or absolute pressure measurements.

The S26 Series Seal System is a protective device used to isolate 2600T series transmitters from the process fluid.

The seal system provides a flexible diaphragm seal between the process fluid and a liquid filled capillary tube connected to the body of the transmitter. The diaphragm isolates the process fluid while the filled capillary tube hydraulically transmits the process pressure to the transmitter sensor. The capillary of remote seal is corrosion-resistant with robust costruction in stainless steel with spiral armour protection, also PVC jacket; PVC protection is always recommended except for high temperature application, where stainless steel armour is suggested.

The all welded construction assures reliable operation over the widest range of operating temperature and under vacuum conditions.

For certain applications, use of seal is necessary to prevent the process fluid from leaving its enclosure, due to reasons such as:

- the process fluid has solids in suspension or is highly viscous and can foul impulse lines.
- the process fluid can solidify in impulse lines or the transmitter
- the process fluid is too hazardous to enter the control area where the transmitter is located.
- the process temperature exceeds the recommended limits for the transmitter.
- the application is interface level or density measurement.
 Remote seals offer the required constant and equal specific gravity of the pressure transfer fluid on the high and low sides of the transmitter.
- the transmitter must be located away from the process for easier maintenance.

The S26 series is available with process connections for ANSI or DIN pipe flanges, wedge flow elements, chemical tees, and threaded pipe fittings. Extended diaphragm remote seals, suitable for connection to 2in - 3in or 4in flanged tank nozzles or flanged tees, permit the seal diaphragm to be located flush with the inside of a tank or pipe. Sanitary type seals meet the stringent requirements of sanitary food, dairy, pharmaceutical and Bio Tech applications, offering FDA approved fillings and compliance with 3-A Sanitary Standards.

Fill fluids with FDA are defined as food fills and are Generally Recognized As Safe (GRAS) by the US Food and Drug Administration (FDA).

Seal system selection criteria

Application of an S26 system in direct mount or remote seal configuration to 2600T transmitters affects performances of original devices. Effects are evident in:

- Accuracy
- Temperature effects
- Dynamic response

Accuracy

Accuracy is only marginally affected when seal diaphragm stiffness is relevant compared with sensor stiffness. This is the only characteristic of the S26 system which has role on accuracy performance. High stiffness of diaphragm associated with low URL might produce increased errors of linearity, hysteresis, and long term stability; when diaphragm stiffness is accuracy related also temperature effects are significantly affected. Some basic considerations on diaphragm stiffness help understanding effects introduced by S26 system associated with transmitters. This is physically defined by the ratio between the pressure variation applied to the diaphragm and the corresponding volume variation. The stiffness is not linear along the whole diaphragm volumetric displacement, but the S26 design is such to maintain the system linear within the service conditions of the transmitter such as:

- Operating pressure range
- Operating static pressure (for differential transmitters)
- Ambient & process temperature limits

Diaphragm stiffness is a function of material & thickness (elastic coefficient), diameter (type), convolution shape and geometry (design defined)

• Temperature effects

S26 system has effect on temperature performance of the complete transmitter. This effect is mostly on zero of the instrument and is produced by the expansion of the fill fluid into the closed volume formed by the transmitter flange cavity the capillary volume and the remote seal volume. This volume filled with a fluid with specific expansion coefficient; change in temperature of the measuring device produce a volume variation which is absorbed by the remote diaphragm, whose stiffness produces a change in the fluid pressure: this is the zero error. In real application the transmitter/seal system is not the same and stable temperature. Therefore the errors referred in this document for each type of diaphragm and different fluids should be taken as a reference for qualitatively evaluation and not a true behaviour in normal application conditions. Should again be recognized that the stiffness of diaphragm and in this case, the thermal coefficient of fluid are the parameter to take into account.

Time response

Application of S26 seal to transmitters increases the original time response. The amount of the increase depends from the number of elements and condition of the instrument as follows:

- transmitter sensor range
- physical configuration (i.e. a remote seal on other side)
- type of measure/number of seal (one or two)
- fill fluid viscosity of the S26 system applied
- ambient temperature (affects the transmitter and the capillary) and process temperature on the seal diaphragm
- capillary length

Models S264

The delay introduced by the seal may be considered as an added constant time to the one of the associated transmitter For obtaining the best application solution:

- choose sensor code with URL closest to application SPAN
- select largest diameter diaphragm seal related to URL.
- keep the capillary length as short as possible
- · select the fill fluid that suits the most extreme process conditions expected (highest temperature and lowest pressure) and it is compatible with the process fluid.
- In vacuum application, choose always the all welded version and mount the transmitter primary 30 cm/12 inches or more below the bottom seal connection.
- In a two-seal system use the same diaphragm size, capillary length and fill fluid on each side of the transmitter.

Ordering Information

The transmitter and each seal system are each identified by a product code number. These code numbers are stamped on the transmitter nameplate and each character identifies specific product features. Refer to ordering information for a detailed explanation of the product code numbers.

A typical example of the product code stamping is as follows:

Transmitter Product Code 264DRFSSA1AH-V1E1D3 Seal System Product Code S264WHBCDFSBEH1

Industrial application in chemical, sanitary, food and any other process industries may require seal configurations and/or process connection different from those reported in this document. Each "special" should be evaluated by ABB to check the correctness and its level of functionality.

Ask for the "S26 series seal form" to define precisely the measuring problem and application requirements.

The following table shows the types of standard seals considered in this leaflet.

The mnemonics will be used as shortest cross references with the transmitter data sheet which should be read in conjunction with this data sheet.

Model	Seal type	Size	Mnemonic
S264W	Wafer Wafer (food)	1 ½in / DN40 2in / DN50 3in / DN80	P1.5 P2 P3
S264C	Chemical tee flanged	3in	P3
	Flanged flush diaphragm	2in / DN50 3-4in / DN80-100	P2 P3
S264F	Flanged extended diaphragm	2in / DN50 3in / DN80 4in / DN100	E2 E3 P3
S264U	Union	1 ½n	P1.5
S264T	Threaded off-line	2 ½in	T2.5
S264M	Flanged off-line	2 ½n	T2.5
S264S	Union nut Triclamp Cherry Burrel Sanitary, Aseptic	2in / F50 3in / F80 4in	S2 S3 S3
S264B	Button	1in	B1
S264P	Urea service flanged	1 ½in 2 ½in	U1.5 U2.5

ABB can also cooperate with you by developing a special remote seal for problems requiring individual solutions.

Please contact your local ABB office or representative for additional information.

FILL FLUID CHARACTERISTICS (Table A)

FILL FLUIDS	OPERATING CONDITIONS				SPECI	FICATION AT 25	° C (77° F)
(APPLICATION)	Tmax @ Pabs>of	Pmin mbar abs (psia)	Tmax @ P min	Tmin	Specific gravity	Kinematic viscosity (cSt)	Thermal expansion (x 10 ⁻³ / ° C)
Silicone oil-DC200™	200 (390)	0.7	160	-40	0.934	10	1.08
(General purpose)	@ 35mbar	(0.01)	(320)	(-40)	0.004	10	1.00
Silicone oil-AN140™	380 (716)	0.7	300	- 5	1.07	40	0.64
(High temperature)	@ 1bar	(0.01)	(572)	(+23)	1.07	40	0.04
Silicone Polymer–Syltherm XLT™	100 (212)	2	20	-100	0.852	1.4	4
(Low temperature)	@ 110mbar	(0.03)	(68)	(-148)	0.002	1.4	'
Vegetable oil-Neobee M-20™	200 (390)	130	150	-18	0.92	9.8	1.2
(Food-Sanitary) FDA	@ 1bar	(1.9)	(300)	(O)	0.92	9.0	1.2
Glycerin Water (70%)	93 (200)	1000	93	-7	1.08	2.2	0.36
(Food-Sanitary) FDA	@ 1bar	(14.5)	(200)	(+20)	1.06	2.2	0.36
Mineral oil-MARCOL 82™	200 (390)	33	40	-40	0.04	26	1.04
(Food-Sanitary) FDA	@ 200mbar	(0.5)	(104)	(-40)	0.84	20	1.04
Inert – Galden™	160 (320)	0.7	65	-18	1.00	0	4.4
(Oxygen Service)	@ 1bar	(0.01)	(150)	(O)	1.82	9	1.1
Inert - Halocarbon™4.2	180 (356)	4	70	-20	1.07	6.0	0.064
(Oxygen Service)	@ 400mbar	(0.06)	(158)	(-4)	1.87	6.3	0.864
ABB fill	300 (572)	0.7	160	-10	1.04	16	0.00
(Paints and specials)	@ 400mbar	(0.01)	(320)	(+14)	1.04	16	0.92

Absolute viscosity (cP) = Kinematic Viscosity (cSt) x Specific gravity at specified temperature.


The absolute viscosity value is used for response time calculation.

SEALS DIMENSIONS ON FOLLOWING PAGES ARE IN mm (in)


S264W Model Wafer Remote Seal

The wafer remote seal is designed to be clamped between two ANSI or DIN raised face flanges. The diaphragm side of the seal faces the process flange and a blind back-up flange is used on the other side of the seal.


The wafer variant is also available as food design for $1^{1}/2$ in and 3in sizes.



Size	DIMENSIONS mm (in)						
Size	A (dia)	B (dia)	н				
1 ¹ / ₂ in	47 (1.85)	73.2 (2.87)	23 (0.9)				
2in	60 (2.36)	92.1 (3.62)	23 (0.9)				
3in	89 (3.5)	127 (5)	23 (0.9)				
DN 40	47 (1.85)	88 (3.46)	23 (0.9)				
DN 50	60 (2.36)	102 (4.02)	23 (0.9)				
DN 80	89 (3.5)	138 (5.43)	23 (0.9)				



1 1/2 in wafer food design



3in wafer food design

Maximum Working Pressure

WAFER SEAL ELEMENT: 16 MPa, 160 bar, 2320 psi but not greater than the backup flange rating (not supplied).

Vacuum Service

Full vacuum subject to fill fluid limits. Refer to table A.

Minimum pressure with tantalum diaphragm is 1 kPa abs, 10 mbar abs, 0.15 psia.

Process Temperature Limits

Same as fill fluid limits. Refer to table A. 260°C (500°F) for Tantalum diaphragm.

204°C (400°F) for use with Teflon anti-stick coating.

Gasket seat finish

smooth (RF or DIN): 0.8μm (32AARH) serrated (RF): 3.2 to 6.3μm (125 to 250AARH)

Form C (DIN 2526): 160RZ Form E (DIN 2526): 16RZ

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- a) the seal (one element)
- b) the capillary per meter
- c) the system (transmitter sensor when combined with a seal of specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm materials.

For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics table.

THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO SIDES

Wafer Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
1 ¹ / ₂ in / DN 40	0.87kPa, 8.7mbar, 3.5inH₂O	0.3kPa, 3mbar, 1.2inH₂O	0.9kPa, 9mbar, 3.6inH2O
2in / DN 50	0.29kPa, 2.9mbar, 1.16inH2O	0.07kPa, 0.7mbar, 0.28inH2O	0.2kPa, 2mbar, 0.8inH ₂ O
3in / DN 80	0.09kPa, 0.9mbar, 0.36inH2O	0.03kPa, 0.3mbar, 0.12inH2O	0.03kPa, 0.3mbar, 0.12inH2O

BASIC ORDERING INFORMATION model S264W Wafer Remote Seal

Select one character or set of characters from each category and specify complete catalog number.


BASE MODEL – 1st to 5th characters	S 2	6 4 W X	Х	Х	Х	F	Х	Х	Х	Х	Х
Wafer Remote Seal											
Transmitter side of connection – 6th character											
High side		Н									
Low side Centering system – 7 th character		L	J								
Seat on back diameter (suitable fot RF backup flange)			В								
Size - 8 th character											
1 ½in ANSI				Α							
2in ANSI 3in ANSI				ВС							
1 ½ in ANSI food design				1							
3in ANSI food design				2							
DIN DN40 DIN DN50				D E							
DIN DN80				F							
Seat finish – 9 th character											
Serrated finish (suitable for RF)	(Notes 1, 3)				D						
Smooth finish (suitable for RF) Serrated finish to DIN 2526 Form C (up to PN40)	(Note 1) (Notes 2, 3)				E R						
Serrated finish to DIN 2526 Form E (PN64 to PN160)	(Notes 2, 3)				S						
Smooth finish (suitable for DIN)	(Notes 2, 3)				Т						
Use code – 10 th character											
Diaphragm material - 11th character											
AISI 316 L ss	(Note 4)		NAC				S				
Hastelloy C276™ Tantalum	(Note 4) (Note 4)		NAC	JΕ			H				
AISI 316 L ss with anti-stick coating	(Notes 4, 5)		NAC				Κ				
Hastelloy C276™ with anti–stick coating	(Notes 4, 5)		NAC				Y				
AISI 316 L ss with anti-corrosion and anti-stick coating Capillary protection – 12 th character	(Notes 4, 6)		NAC	ノニ			W				
AISI 316 ss armour	(RECOMMENDED FOR HIGH TEMPERATURE)							A			
AISI 316 ss armour with PVC protective cover	(HEOOMINIENDED FORTHIGH FEMILE ENVIOLE)							В			
Capillary length m (feet) - 13th character											
1 (3)									Α		
1.5 (5) 2 (7)									B C		
2.5 (8)									D		
3 (10)									Е		
3.5 (12) 4 (13)									F G		
4.5 (15)									H		
5 (17)									J		
5.5 (18)									K L		
6 (20) 6.5 (22)									М		
7 (23.5)									Ν		
7.5 (25)									Р		
8 (27) 9 (30)									Q R		
10 (33)									S		
12 (40)									Т		
14 (47) 16 (53)									V		
Fill fluid - 14th character											
Silicone oil										S	
Inert fluid - Galden Inert fluid - Halocarbon	(Notes 3, 7) (Notes 3, 7)									N D	
ABB fill	(Note 3)									K	
Sllicone oil for high temperature	(Note 3)									Н	
Silicone polymer for low temperature	(Note 3)									C	
Mineral oil (FDA approved) Vegetable oil (FDA approved)	(Note 8) (Note 8)									W A	
Glycerin-water (FDA approved)	(Note 8)									В	
Certification – 15 th character											
None Zone "0" protection	(Note 9)										1
											2

- Note 1: Not available with DIN size code D, E, F Note 2: Not available with ANSI size code A, B, C Note 3: Not available with food design size code 1, 2 Note 4: Not available with serrated seat code D, R, S Note 5: Not available with size code A, B, D, E, F, 1, 2 Note 6: Not available with size code A, D, 1, 2 Note 7: Suitable for oxygen service
- Note 8: Suitable for food application
- Note 9: Not available with diaphragm material code K, Y
- Hastelloy is a Cabot Corporation trademark
- Galden is a Montefluos trademark
- Halocarbon is a Halocarbon Products Co. trademark

S264C Model Chemical Tee Remote Seal

The chemical tee remote seal is designed to connect to a Wedge Flow Element or to any process fitting with appropriate mating condition.

Chemical tee elements cannot be connected to a standard ANSI or DIN pipe flange.



Maximum Working Pressure

2 MPa, 20 bar, 300 psi

Vacuum Service

Full vacuum subject to fill fluid limits. Refer to table A.

Process Temperature Limits

Same as fill fluid limits. Refer to table A. 204°C (400°F) for use with Teflon anti-stick coating. 204°C (400°F) with PTFE gasket 340°C (645°F) with graphite gasket

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- the seal (one element)
- b) the capillary per meter
- the system (transmitter sensor when combined with a seal of C) specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm materials.


For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics table.

THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO

Chemical Tee Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
3in	0.09kPa, 0.9mbar, 0.36inH ₂ O	0.03kPa, 0.3mbar, 0.12inH ₂ O	0.03kPa, 0.3mbar, 0.12inH2O

BASIC ORDERING INFORMATION model S264C Chemical Tee Remote Seal

Select one character or set of characters from each category and specify complete catalog number.



Note 1: Suitable for oxygen service Note 2: Suitable for food application


TM Hastelloy is a Cabot Corporation trademark

Galden is a Montefluos trademark

Halocarbon is a Halocarbon Products Co. trademark

S264F Model Flanged Extended and Flush Diaphragm Remote Seal

The extended and flush diaphragm remote seal is designed to connect to ANSI or DIN flanged pipe fitting. For liquid level measurement installations the seal connects to an ANSI or DIN flanged tank nozzle (Schedule 40).



Flanged Extended Diaphragm Seal

Flanged Flush Diaphragm Seal

		Dimensions mm (in)							
Size/Rating	A	(dia)	B (dia)	C (dia)	D (dia)	E (dia)	F	G	N° of holes
	flush	extended			_ (/	_ (,		_	
2in ANSI CL 150	60 (2.36)	48 (1.9)	92.1 (3.62)	120.5 (4.74)	152.5 (6)	20 (0.79)	19.5 (0.77)	9.5 (0.37)	4
2in ANSI CL 300	60 (2.36)	48 (1.9)	92.1 (3.62)	127 (5)	165 (6.5)	20 (0.79)	22.5 (0.88)	9.5 (0.37)	8
2in ANSI CL 600	60 (2.36)	NA	92.1 (3.62)	127 (5)	165 (6.5)	20 (0.79)	25.5 (1)	9.5 (0.37)	8
2in ANSI CL 900	60 (2.36)	NA	92.1 (3.62)	165 (6.5)	216 (8.5)	26 (1.02)	38.5 (1.51)	9.5 (0.37)	8
3in ANSI CL 150	89 (3.5)	72 (2.83)	127 (5)	152.5 (6)	190.5 (7.5)	20 (0.79)	24 (0.94)	9.5 (0.37)	4
3in ANSI CL 300	89 (3.5)	72 (2.83)	127 (5)	168.5 (6.63)	210 (8.26)	22 (0.86)	28.5 (1.12)	9.5 (0.37)	8
3in ANSI CL 600	89 (3.5)	NA	127 (5)	168.5 (6.63)	210 (8.26)	22 (0.86)	32 (1.26)	9.5 (0.37)	8
3in ANSI CL 900	89 (3.5)	NA	127 (5)	190.5 (7.5)	241 (9.48)	26 (1.02)	38.5 (1.51)	9.5 (0.37)	8
4in ANSI CL 150	89 (3.5)	94 (3.7)	157.2 (6.2)	190.5 (7.5)	228.6 (9)	20 (0.79)	24 (0.94)	9.5 (0.37)	8
4in ANSI CL 300	89 (3.5)	94 (3.7)	157.2 (6.2)	200.2 (7.88)	254 (10)	22 (0.86)	32 (1.26)	9.5 (0.37)	8
DN50 DIN PN16	60 (2.36)	48 (1.9)	102 (4.02)	125 (4.92)	165 (6.5)	18 (0.71)	20 (0.79)	9.5 (0.37)	4
DN50 DIN PN40	60 (2.36)	48 (1.9)	102 (4.02)	125 (4.92)	165 (6.5)	18 (0.71)	20 (0.79)	9.5 (0.37)	4
DN50 DIN PN64	60 (2.36)	NA	102 (4.02)	135 (5.31)	180 (7.08)	22 (0.86)	26 (1.02)	9.5 (0.37)	4
DN50 DIN PN100	60 (2.36)	NA	102 (4.02)	145 (5.71)	195 (7.67)	26 (1.02)	28 (1.1)	9.5 (0.37)	4
DN50 DIN PN160	60 (2.36)	NA	102 (4.02)	145 (5.71)	195 (7.67)	26 (1.02)	30 (1.18)	9.5 (0.37)	4
DN80 DIN PN16	89 (3.5)	72 (2.83)	138 (5.43)	160 (6.3)	200 (7.87)	18 (0.71)	20 (0.79)	9.5 (0.37)	8
DN80 DIN PN40	89 (3.5)	72 (2.83)	138 (5.43)	160 (6.3)	200 (7.87)	18 (0.71)	24 (0.94)	9.5 (0.37)	8
DN80 DIN PN64	89 (3.5)	NA	138 (5.43)	170 (6.7)	215 (8.46)	22 (0.86)	28 (1.1)	9.5 (0.37)	8
DN80 DIN PN100	89 (3.5)	NA	138 (5.43)	180 (7.08)	230 (9.05)	26 (1.02)	32 (1.26)	9.5 (0.37)	8
DN80 DIN PN160	89 (3.5)	NA	138 (5.43)	180 (7.08)	230 (9.05)	26 (1.02)	36 (1.42)	9.5 (0.37)	8
DN100 DIN PN16	89 (3.5)	94 (3.7)	158 (6.22)	180 (7.08)	220 (8.66)	18 (0.71)	20 (0.79)	9.5 (0.37)	8
DN100 DIN PN40	89 (3.5)	94 (3.7)	162 (6.38)	190 (7.48)	235 (9.25)	22 (0.86)	24 (0.94)	9.5 (0.37)	8

SS/S264_3

Maximum Working Pressure (20 to 120°C; 68 to 248°F)

ANSI CL 150: 2 MPa, 20 bar, 290 psi ANSI CL 300: 5 MPa, 50 bar, 725 psi ANSI CL 600: 10 MPa, 100 bar, 1450 psi ANSI CL 900: 16 MPa, 160 bar, 2320 psi DIN PN 16: 1.6 MPa, 16 bar, 230 psi DIN PN 40: 4 MPa, 40 bar, 580 psi DIN PN 64: 6.4 MPa, 64 bar, 930 psi DIN PN100: 10 MPa, 100 bar, 1450 psi DIN PN160: 16 MPa, 160 bar, 2320 psi

Vacuum Service

Models S264

Full vacuum subject to fill fluid limits. Refer to table A.

Minimum pressure with tantalum diaphragm is 1kPa abs, 10mbar abs, 0.15psia.

Process Temperature Limits

Same as fill fluid limits. Refer to table A. 260°C (500°F) for Tantalum diaphragm. 204°C (400°F) for use with Teflon anti-stick coating.

Gasket seat finish

smooth (RF or DIN): 0.8 μ m (32AARH) serrated (RF): 3.2 to 6.3 μ m (125 to 250AARH)

Form C (DIN 2526): 160RZ Form E (DIN 2526): 16RZ

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- a) the seal (one element)
- b) the capillary per meter
- the system (transmitter sensor when combined with a seal of specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm materials.

For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics table

THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO SIDES

Flanged Extended Diaphragm Remote Seal

Flanged Extended Diaphragm Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
2in / DN 50	0.3kPa, 3mbar, 1.2inH ₂ O		0.3kPa, 3mbar, 1.2nH ₂ O
3in / DN 80	0.15kPa, 1.5mbar, 0.6inH ₂ O 0.08kPa, 0.8mbar, 0.32inH ₂ O		0.07kPa, 0.7mbar, 0.28inH2O
4in / DN 100	0.09kPa, 0.9mbar, 0.36inH2O		0.03kPa, 0.3mbar, 0.12inH2O

Flanged Flush Diaphragm Remote Seal

Flanged Flush Diaphragm Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
2in / DN 50	0.29kPa, 2.9mbar, 1.16inH2O	0.07kPa, 0.7mbar, 0.28inH2O	0.2kPa, 2mbar, 0.8inH2O
3in / DN 80	0.09kPa, 0.9mbar, 0.36inH2O	9kPa, 0.9mbar, 0.36inH2O 0.03kPa, 0.3mbar, 0.12inH2O 0.03kPa	
4in / DN 100	0.09kPa, 0.9mbar, 0.36inH2O	kPa, 0.9mbar, 0.36inH ₂ O 0.03kPa, 0.3mbar, 0.12inH ₂ O 0.03kPa, 0.3mbar,	

BASIC ORDERING INFORMATION model S264F Flanged Remote Seal (flush and extended)

Select one character or set of characters from each category and specify complete catalog number.

BASE MODEL – 1st to 5	th characters		S 2 6 4	F X X	Х	Х	Х	Х	Х
Flanged Remote seal ((flush and extended)								
Transmitter side of co	nnection - 6th character								
High side				Н					
Low side				L					
Mounting flange - 7th c	haracter								
Rotating				R					
Size - 8 th character									
2in	ANSI CL 150				Α				
2in	ANSI CL 300				D				
2in	ANSI CL 600				G				
2in	ANSI CL 900				J				
3in	ANSI CL 150				В				
3in food design	ANSI CL 150				1				
3in	ANSI CL 300				Ε				
3in	ANSI CL 600				Н				
3in	ANSI CL 900				K				
4in	ANSI CL 150				С				
4in	ANSI CL 300				F				
DN50	DIN PN 16/40				М				
DN50	DIN PN 64				Р				
DN50	DIN PN 100				R				
DN50	DIN PN 160				W				
DN80	DIN PN 16				N				
DN80	DIN PN 40				L				
DN80	DIN PN 64				Q				
DN80	DIN PN 100				S				
DN80	DIN PN 160				Y				
DN100	DIN PN 16				Т				
DN100	DIN PN 40				Ü				
	form (seal) - 9th character					1			
Carbon steel	Form RF (raised face) - serra	ated finish	(Notes 1, 3)			Α			
Carbon steel	Form RF (raised face) - smo		(Notes 1, 3)			В			
Carbon steel	DIN 2526 – Form C/E – serra		(Notes 2, 3)			G			
Carbon steel	DIN 2526 – Form C/E – smo		(Notes 2, 3)			Р			
AISI 316 ss	Form RF (raised face) – serra		(Notes 1, 3)			D			
AISI 316 ss	Form RF (raised face) - smo		(Note 1)			E			
AISI 316 ss	DIN 2526 – Form C/E – serra		(Notes 2, 3)			L			
AISI 316 ss	DIN 2526 – Form C/E – smo		(Notes 2, 3)			Q			
	material – 10th character		(140100 2, 0)			Q			
Flush (see next for dia							F		
50mm (2in)	priragin material)	AISI 316 L ss	(Notes 3, 4)				1		
50mm (2in)		Hastelloy 276™	(Notes 3, 4)				2		
100mm (4in)		AISI 316 L ss	(Notes 3, 4, 6)				3		
100mm (4in)		Hastelloy 276™	(Notes 3, 4)				4		
150mm (6in)		AISI 316 L ss	(Notes 3, 4, 6)				5		
150mm (6in)		Hastelloy 276™	(Notes 3, 4)				6		
Diaphragm material (se	eal) = 11th character	nastelloy 270***	(Notes 3, 4, 6)				0		
	- I ona actor		(Noto E)	N.	ACE			S	
AISI 316 L ss			(Note 5) (Note 6)		ACE			Н	
Hastelloy C276™ Tantalum			(Note 6) (Notes 6, 7)	IN	AUE			Т	
AISI 316 L ss with anti	i_stick coating		(Notes 5, 7) (Notes 5, 6, 8)	N	ACE			K	
Hastelloy C276™with a	o a constant of the constant o		(Notes 6, 8)		ACE			Y	
	i-corrosion and anti-stick coating		(Notes 5, 6)		ACE			W	
Capillary protection –			(INOLES 5, 6)	- IN	AUE			VV	1
AISI 316 ss armour		(RECOMMENDED FOR HIGH	TEMPERATURE)						Α
	th PVC protective cover	(LOOWINE NOLD OTT HOLE	Livii Livii OliLj						В

Models S264

BASIC ORDERING INFORMATION S264F		X	Х	X
Capillary length m (feet) - 13th character				
1 (3) 1.5 (5) 2 (7) 2.5 (8) 3 (10) 3.5 (12) 4 (13) 4.5 (15) 5 (17) 5.5 (18) 6 (20) 6.5 (22) 7 (23.5) 7.5 (25) 8 (27) 9 (30) 10 (33) 12 (40) 14 (47) 16 (53) Fill fluid - 14 th character		A B C D E F G H J K L M N P Q R S T U V		
Silicone oil Inert fluid - Galden Inert fluid - Halocarbon ABB fill Sllicone oil for high temperature Silicone polymer for low temperature Mineral oil (FDA approved) Vegetable oil (FDA approved)	(Notes 3, 9) (Notes 3, 9) (Note 3) (Note 3) (Note 3) (Note 10) (Note 10)		SNDKHCWA	
Glycerin-water (FDA approved) Certification – 15 th character	(Note 10)		В	
None Zone "0" protection	(Note 11)			1 2

- Note 1: Not available with DIN mounting flange code $\,$ M, P, R, W, N, L, Q, S, Y, T, U
- Note 2: Not available with ANSI mounting flange code A, D, G, J, B, E, H, K, C, F
- Note 3: Not available with 3in ANSI CL150 food design size code 1
- Note 4: Not available with ANSI CL 600 and ANSI CL 900 mounting flange rating code G, J, H, K and with DIN PN64, PN100, and PN160 mounting flange code P, R, W, Q, S, Y
- Note 5: Not available with Hastelloy C276 extension code 2, 4, 6
- Note 6: Not available with serrated seat finish code A, G, D, L
- Note 7: Not available with extension code 1, 2, 3, 4, 5, 6
- Note 8: Not available with 2in, DN50, DN80, DN100 mounting flange code A, D, G, J, M, P, R, W, N, L, Q, S, Y, T, U
- Note 9: Suitable for oxygen service
- Note 10: Suitable for food application
- Note 11: Not available with Diaphragm material code K, Y


[™] Hastelloy is a Cabot Corporation trademark

TM Galden is a Montefluos trademark

[™] Halocarbon is a Halocarbon Products Co. trademark

S264T Model Off-line Threaded Connection Remote Seal

The off-line threaded connection remote seals are designed to connect directly to a process pipe via the NPT connection in the lower housing. These elements are available with a flushing connection in the lower housing.



Size	Dimensions	mm (in)
Size	D (dia)	Q
1/4in NPT	109.2 (4.3)	53.3 (2.1)
1/2in NPT	109.2 (4.3)	53.3 (2.1)
1in NPT	109.2 (4.3)	63.5 (2.5)
1 ½in NPT	109.2 (4.3)	63.5 (2.5)

Maximum Working Pressure (20 to 120°C; 68 to 248°F)

16 MPa, 160 bar, 2320 psi @ 38°C (100°F).

Vacuum Service

Full vacuum subject to fill fluid limits. Refer to table A.

Minimum pressure with tantalum diaphragm is 1kPa abs, 10mbar abs, 0.15psia.

Process Temperature Limits

Same as fill fluid limits but not greater than 200°C (392°F) due to gasket material. Refer to table A.

-20°C (-4°F) minimum with Viton gasket

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- a) the seal (one element)
- the capillary per meter b)
- the system (transmitter sensor when combined with a seal of C) specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm materials.

For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics

THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO SIDES

Off-Line Threaded Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
2 ¹ / ₂ in	0.32kPa, 3.2mbar, 1.28inH₂O	0.18kPa, 1.8mbar, 0.72inH2O	0.15kPa, 1.5mbar, 0.6inH ₂ O

BASIC ORDERING INFORMATION model S264T Off-Line Threaded Connection Remote Seal

Select one character or set of characters from each category and specify complete catalog number.

Off-ine threaded remote seel	BASE MODEL – 1st to 5th characters		S 2	6	4 T	Y	Y	Х	Y	Y	Y	Y	Y	Х	Х
Transmitter side of connection - 6" character			3 2	0	- '	^	^	^	^	^	^	^	^	^	^
High side High															
L Size - 7° character						Н									
Size = 7" character															
7. Juin NPT-If Vini NPT-If 1 In NPT-If 1 I							J								
In NPT-f							1								
1 /sin NFT-1															
Bolts - 8" character ASI 316 Les Carbon steel ASI 316 Les Carbon steel ASI 316 Se Roy great 1 ASI 316 Se Rastelloy C276TM 2 Diaphrage material - 10" character ASI 316 Se Rastelloy C276TM 2 Diaphrage material - 10" character ASI 316 Se Rastelloy C276TM 1 Tantalum T Capillary protection - 11" character ASI 316 Se armour with PVC protective cover B Capillary length m (feet) - 12" character 1 (3) A A B B B B B B B B B B B B B B B B B B															
ASI 316 L ss							4								
Carbon steel 2															
Alloy steel Flange material – 9" character AISI 316 ss															
Flange material - 9" character															
Hasteloy C276 M	Flange material - 9th character								,						
Hasteloy C276 M	AISI 316 ss								1						
ASI 316 L ss Hastelloy C276™ Taritalum T T Taritalum T T Taritalum T T Taritalum T T T Taritalum T T T T T T T T T T T T T T T T T T T	Hastelloy C276™								2						
Hastelloy C276™	Diaphragm material – 10 th character														
Tantalum T															
Capillary protection - 11" character															
ASI 316 ss armour with PVC protective cover A AISI 316 ss armour with PVC protective cover 1 (3)										I					
AIS 316 ss armour with PVC protective cover Capillary length m (feet) - 12th character 1 (3)		(DEOOL # 45 UDED 500 LUQUI TEL 4050 AT													
Capillary length m (feet) — 12th character 1 (3)		(RECOMMENDED FOR HIGH TEMPERAT	UKE)												
1 (3) 1.5 (5) 2 (7) C 2.5 (8) 3 (10) 3 (10) 3 (10) 3 (10) 3 (12) 4 (13) 4 (13) 4 (15) 5 (17) 5 (18) 6 (20) 6 (20) 1											D				
1.5 (5)												.			
2 (7) C 2.5 (8)															
2.5 (8)															
3 (10)															
3.5 (12)															
4 (13) 4.5 (15) 5.5 (18) 6 (20) 6.5 (22) M 7 (23.5) 7.5 (25) 8 (27) 9 (30) Fill fluid - 13 th character Silicone oil Inert fluid - Galden Inert fluid - Halocarbon Inert															
5 (17) 5.5 (18) 6 (20) 6.5 (22) 7 (23.5) 7 (23.5) 8 (27) 9 (30) Fill fluid - 13 th character Silicone oil Incert fluid - Galden (Note 1) Note 1) Inert fluid - Halocarbon (Note 2) Inert fluid - Halocarbon (Not												G			
5.5 (18) 6 (20)	4.5 (15)											Н			
6 (20) 6.5 (22) 6.5 (22) 7 (23.5) 7 (23.5) 7 (25) 8 (27) 9 (30) 8 (27) 9 (30) Fill fluid - 13th character Silicone oil Inert fluid - Galden (Note 1) Inert fluid - Halocarbon (Note 1) ABB fill Silicone oil for high temperature HSilicone polymer for low temperature Mineral oil (FDA approved) (Note 2) Wyegetable oil (FDA approved) (Note 2) Glycerin-water (FDA approved) (Note 2) B Flushing connections - 14th character Not required Provided (Note 3) Gasket - 15th character															
6.5 (22) 7 (23.5) 7 (23.5) 7.5 (25) 8 (27) 9 (30) Fill fluid – 13th character Silicone oil Inert fluid - Galden (Note 1) Inert fluid - Halocarbon (Note 1) ABB fill Silicone oil for high temperature Silicone polymer for low temperature Silicone polymer for low temperature C Mineral oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Flushing connections – 14th character Not required Provided (Note 3) Gasket – 15th character	, ,														
7 (23.5) 7.5 (25) 8 (27) 9 (30) Fill fluid - 13th character Silicone oil Inert fluid - Galden (Note 1) Inert fluid - Halocarbon (Note 1) Inert fluid - Halocarbon (Note 1) Inert fluid - Halocarbon (Note 1) ABB fill Silicone oil for high temperature Silicone polymer for low temperature Silicone polymer for low temperature C Mineral oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Flushing connections - 14th character Not required Provided (Note 3) Gasket - 15th character PTFE 8															
7.5 (25) 8 (27) 9 (30) P Q Q Q 9 (30) Fill fluid – 13th character Silicone oil															
8 (27)															
9 (30) Fill fluid - 13th character Silicone oil Inert fluid - Galden (Note 1) Inert fluid - Halocarbon ABB fill K Slicone oil for high temperature Silicone polymer for low temperature Silicone polymer for low temperature C Mineral oil (FDA approved) Vegetable oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Flushing connections - 14th character Not required Provided (Note 3) Gasket - 15th character															
Silicone oil S Inert fluid - Galden (Note 1) N Inert fluid - Halocarbon (Note 1) D ABB fill K Silicone oil for high temperature Silicone polymer for low temperature C Mineral oil (FDA approved) (Note 2) W Vegetable oil (FDA approved) (Note 2) A Glycerin-water (FDA approved) (Note 2) B Silicone connections - 14th character Not required Provided (Note 3) Q Casket - 15th character PTFE 2															
Inert fluid - Galden (Note 1) N Inert fluid - Halocarbon (Note 1) D ABB fill K Sllicone oil for high temperature Silicone polymer for low temperature Mineral oil (FDA approved) (Note 2) W Vegetable oil (FDA approved) (Note 2) A Glycerin-water (FDA approved) (Note 2) B Flushing connections - 14th character Not required Provided (Note 3) Q Gasket - 15th character	Fill fluid - 13th character														
Inert fluid - Halocarbon (Note 1) ABB fill Sllicone oil for high temperature Slicone polymer for low temperature C Mineral oil (FDA approved) Vegetable oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Flushing connections – 14th character Not required Provided (Note 3) Gasket – 15th character PTFE 2	Silicone oil												S		
ABB fill Silicone oil for high temperature Silicone polymer for low temperature C Mineral oil (FDA approved) Vegetable oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Glycerin-water (FDA approved) (Note 2) B Flushing connections – 14th character Not required Provided (Note 3) Gasket – 15th character PTFE 2	Inert fluid - Galden												Ν		
Sllicone oil for high temperature Sllicone polymer for low temperature Mineral oil (FDA approved) Vegetable oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) A Glycerin-water (FDA approved) Not required Provided (Note 3) Gasket – 15th character PTFE H H C (Note 2) (Note 2) (Note 2) (Note 3) A 1 2 C Gasket – 15th character		(Note 1)													
Silicone polymer for low temperature Mineral oil (FDA approved) Vegetable oil (FDA approved) (Note 2) Vegetable oil (FDA approved) (Note 2) Glycerin-water (FDA approved) (Note 2) Flushing connections – 14 th character Not required Provided (Note 3) Gasket – 15 th character PTFE 2															
Mineral oil (FDA approved) (Note 2) W Vegetable oil (FDA approved) (Note 2) A Glycerin-water (FDA approved) (Note 2) B Flushing connections – 14 th character Not required 1 Provided (Note 3) Q Gasket – 15 th character															
Vegetable oil (FDA approved) (Note 2) A B Glycerin-water (FDA approved) (Note 2) B Flushing connections – 14th character Not required Provided 1 Q Gasket – 15th character Q Gasket – 15th character PTFE 2		(Note 2)											-		
Glycerin-water (FDA approved) (Note 2) B	Vegetable oil (FDA approved)														
Not required 1 1 Provided (Note 3) Q Gasket – 15th character PTFE 2 2	Glycerin-water (FDA approved)														
Provided (Note 3) Q Gasket – 15th character PTFE 2	Flushing connections - 14th character														
Gasket – 15 th character PTFE 2															
PTFE 2		(Note 3)												Q	
VILON I''' 3															2
	VITON 1181														3


- Note 1: Suitable for oxygen service
- Note 2: Suitable for food application
- Note 3: Not available with Size code 4
- TM Hastelloy is a Cabot Corporation trademark
- TM Viton is a Dupont de Nemour trademark
- TM Galden is a Montefluos trademark
- Halocarbon is a Halocarbon Products Co. trademark

SS/S264_3

Models S264

S264M Model Off-line Flanged Connection Remote Seal

The off-line threaded connection remote seals are designed to connect directly to ANSI or DIN flanged tank nozzles. These elements are available with a flushing connection in the lower housing, selectable on request in the ordering code.



Connection		Dimensions mm (in)							
Connection Size	Rating	A (dia)	D (dia)	C (4	4 studs)	D (dia)	E (dia)	F	
O.Z.C		A (dia)	B (dia)	Length	Thread	D (dia)	E (dia)		
1in	ANSI CL 150	110 (4.33)	79.4 (3.12)	39 (1.53)	1/2in – 13 UNC	50.8 (2)	26.7 (1.05)	1.6 (0.06)	
	ANSI CL 300	124 (4.88)	88.9 (3.5)	51 (2)	5/8in – 11 UNC		20.7 (1.00)	1.0 (0.00)	
1 1/ in	ANSI CL 150	127 (5)	98.4 (3.87)	39 (1.53)	1/2in – 13 UNC	70 (0.07)	44 (4 04)	44 (4 04)	1.6 (0.06)
1 ¹ / ₂ in	ANSI CL 300	155 (6.1)	114.3 (4.5)	57 (2.24)	3/4in - 10 UNC	73 (2.87)	41 (1.61)	1.6 (0.06)	
DN 25	DIN PN 16-40	115 (4.52)	85 (3.34)	42 (1.65)	M12	68 (2.67)	28.5 (1.12)	2 (0.07)	
DN 40	DIN PN 16-40	150 (5.9)	110 (4.33)	48 (1.89)	M16	88 (3.46)	43.1 (1.69)	3 (0.12)	

Maximum Working Pressure (20 to 120°C; 68 to 248°F)

ANSI CL 150: 2 MPa, 20 bar, 290 psi ANSI CL 300: 5 MPa, 50 bar, 725 psi DIN PN 16-40: 4 MPa, 40 bar, 580 psi

Vacuum Service

Full vacuum subject to fill fluid limits. Refer to table A.

Minimum pressure with tantalum diaphragm is 1kPa abs, 10mbar abs, 0.15psia.

Process Temperature Limits

Same as fill fluid limits but not greater than 200°C (392°F) due to gasket material. Refer to table A.

-20°C (-4°F) minimum with Viton gasket

Gasket seat finish

serrated (RF): 3.2 to 6.3 µm (125 to 250AARH)

Form C (DIN 2526): 160RZ

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- the seal (one element) a)
- b) the capillary per meter
- the system (transmitter sensor when combined with a seal of C) specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm materials.

For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics table.


THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO SIDES.

Off-Line Flanged Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
2 ¹ / ₂ in	0.32kPa, 3.2mbar, 1.28inH2O	0.18kPa, 1.8mbar, 0.72inH2O	0.15kPa, 1.5mbar, 0.6inH2O

Models S264

BASIC ORDERING INFORMATION model S264M Off-line Flanged Connection Remote Seal

Select one character or set of characters from each category and specify complete catalog number.



- Not available with DIN mounting flange code M, N Note 1:
- Not available with ANSI mounting flange code A, B, C, D Note 2:
- Note 3: Suitable for oxygen service
- Note 4: Suitable for food application

- TM Hastelloy is a Cabot Corporation trademark
- TM Viton is a Dupont de Nemour trademark
- Galden is a Montefluos trademark
- Halocarbon is a Halocarbon Products Co. trademark

SS/S264 3


Models S264

S264U Model Union Connection Remote Seal (To be used only for gauge pressure)


The union connection remote seal are used exclusively for pressure measurement with gauge pressure transmitter.


The seal is available with an optional weld bushing, or with an optional chemical tee flange. The remote seal with a weld bushing, includes a bushing which provides the mating surface for the seal element. The union connection seal with a chemical tee flange, is designed to connect to any process fitting which accepts a chemical tee seal element (refer to Chemical Tee Seal for more information). The union seal connects to the chemical tee flange which serves as an adaptor to permit connection of the union seal to a chemical tee type fitting.

134 (5.3) 29 (1.14) 16 (0.63) Union Connection 61 42 (1.65) dia 41 (1. 5 <u>di</u> dia 9 (0.35) 14 (0.55) Capillary to 2 (0.08) Instrument



Union Connection Seal without weld bushing





Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- a) the seal (one element)
- b) the capillary per meter
- C) the system (transmitter sensor when combined with a seal of specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm materials.

For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics table.

Maximum Working Pressure

Union Connection: 10.3 MPa, 103 bar, 1500 psi With Chemical Tee Flange: 2 MPa, 20 bar, 300 psi

Vacuum Service

Full vacuum subject to fill fluid limits.

Refer to table A.

Process Temperature Limits

Same as fill fluid limits.

Refer to table A.

204°C (400°F) with silicone rubber O-ring


260°C (500°F) with Teflon TFE O-ring

Union Connection Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
1 ¹ / ₂ in	0.87kPa, 8.7mbar, 3.5inH2O	0.3kPa, 3mbar, 1.2inH ₂ O	0.9kPa, 9mbar, 3.6inH2O

Models S264

BASIC ORDERING INFORMATION model S264U Union Connection Remote Seal

Select one character or set of characters from each category and specify complete catalog number.



Note 1: Suitable for oxygen service Note 2: Suitable for food application

Hastelloy is a Cabot Corporation trademark


Galden is a Montefluos trademark


Halocarbon is a Halocarbon Products Co. trademark

S264S Food and Sanitary Remote Seals

The Union Nut and Triclamp remote seals are designed for connection by Union Nut according to DIN 11851 -F50 or F80 and 2 in, 3 in, 4 in Triclamp sanitary fittings. A variety of gaskets and clamp rings for the seals are available.








Union Nut Seal (to DIN 11851)

	Union Nut			
	F50	F80		
A (dia)	68 (2.68)	100 (3.93)		
B (RD)	78 (3.07)	110 (4.33)		
С	16 (0.63)	19 (0.74)		

Triclamp Seal

	Triclamp					
	2in	3in	4in			
A (dia)	56.3 (2.2)	83 (3.26)	110.3 (4.34)			
B (dia)	64 (2.5)	91 (3.58)	119 (4.68			


The Cherry Burrell remote seals are designed for connection to 2in, 3in or 4in Cherry Burrell I-Line sanitary fittings. A 4in V-band clamp is optionally available for the 4in variant.



Size	DIMENSIONS mm (in)							
Size	A (dia)	B (dia)	C (dia)	D (dia)	E	F	G	н
2in	67 (2.64)	56 (2.2)	42 (1.65)	57(2.24)	3.2 (0.13)	6.5 (0.26)	12.5 (0.49)	3 (0.12)
3in	89 (3.86)	81 (3.19)	72.42 (2.85)	83.8 (3.3)	2.4 (0.09)	7.9 (0.31)	15 (0.59)	3 (0.12)
4in	124 (4.88)	111.25 (4.38)	72.42 (2.85)	109.3 (4.3)	2.4 (0.09	7.9 (0.31)	15 (0.59)	3 (0.12)


The sanitary remote seal with flush diaphragm is designed to connect to a 4in sanitary tank spud. The tank spud and process gasket are available as options with the seal suitable V-band clamp is also available on request.

NOTE: The tank spud required for connection of this seal element must be welded to the process vessel prior to connecting the seal, following arecommended welding and pressure testing procedure.



The sanitary remote seal with extended diaphragm is designed to connect to a 4in sanitary tank spud. The tank spud and process gasket are available with the seal.


NOTE: The tank spud required for connection of this seal element must be welded to the process vessel prior to connecting the seal. Refer to Installing Sanitary Tank Spuds for the spud mounting dimensions and a recommended welding and pressure testing procedure in the S264 instruction manual.



Size	Dimensions mm (in)
Size	Α
2in	53.3 (2.1)
4in	104.1 (4.1)
6in	154.9 (6.1)

The sanitary aseptic remote seal is designed to connect to a 4in sanitary fitting: either an aseptic tank spud or a 4in Cherry Burrell aseptic ferrule. The tank spud, gaskets and V-band clamp are available option with the seal element.

NOTE: The tank spud or ferrule required for connection of this seal element must be welded to the process vessel prior to connecting the element, following recommended welding and pressure testing procedure. Weld the Cherry Burrell ferrule to the process vessel in accordance with manufacturers recommandations.



4in Aseptic Flanged Connection

Maximum Working Pressure @ 20°C (68°F)

2 in Triclamp: 3.8 MPa, 38 bar, 550 psi 3 in Triclamp: 2.4 MPa, 24 bar, 350 psi 4 in Triclamp: 1.7 MPa, 17 bar, 250 psi F50/F80 Union nut: 2.5 MPa, 25 bar, 360 psi Cherry Burrell: 1.9MPa, 19bar, 275psi

4in Sanitary flush or extended or aseptic: 1.9MPa, 19bar, 275psi

4in V-band clamp option: 1MPa, 10bar, 145psi

4in schedule 5 V-band clamp option: 0.7MPa, 7bar, 100psi @ 21°C.

Process Temperature Limits

Same as fill fluid limits. Refer to table A.

Process Gasket Temperature Limits

Buna: -40 to 121°C (-40 to 250°F) Viton: 2 to 177°C (35 to 350°F) Ethylene Propylene: 149°C (300°F)

Vacuum Service

Full vacuum subject to fill fluid limits. Refer to table A.

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- the seal (one element) a)
- b) the capillary per meter
- the system (transmitter sensor when combined with a seal of C) specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm

For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics

THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO SIDES

Union Nut, Triclamp, Cherry Burrell, Sanitary and Aseptic Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
2in / F50	0.7kPa, 7mbar, 2.8nH2O	0.42kPa, 4.2mbar, 1.7inH ₂ O	1.4kPa, 14mbar, 5.6inH ₂ O
3in / F80	0.06kPa, 0.6mbar, 0.24inH ₂ O	0.03kPa, 0.3mbar, 0.12inH2O	0.03kPa, 0.3mbar, 0.12inH ₂ O
4in	0.06kPa, 0.6mbar, 0.24inH ₂ O	0.03kPa, 0.3mbar, 0.12inH2O	0.03kPa, 0.3mbar, 0.12inH ₂ O

Models S264

BASIC ORDERING INFORMATION model S264S Food and Sanitary Remote Seals


Select one character or set of characters from each category and specify complete catalog number.




Note 1: Suitable for food application

[™] Viton is a Dupont de Nemour trademark

S264P Remote seal(s) for Urea Service





Maximum Working Pressure @ 20°C (68°F)

3in, ANSI 600 flange:

- 8 MPa, 80 bar, 1160 psi

2in ANSI 2500 threaded flange:


- 32 MPa, 320 bar, 4640 psi

Vacuum Service

Full vacuum subject to fill fluid limits. Refer to table A.

Process Temperature Limits

Same as fill fluid limits. Refer to table A.



Threaded Flange ANSI 2500, 2in

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for

- the seal (one element) a)
- b) the capillary per meter
- C) the system (transmitter sensor when combined with a seal of specific size/type)

referred to silicone oil (DC 200) filling and AISI 316 L ss diaphragm


For filling different from silicone oil (DC200) the errors can be multiplied by the thermal expansion coefficient listed in the fill fluid characteristics table.

THE ERRORS IN TABLE CAN BE CONSIDERED DIVIDED BY 4 FOR TRANSMITTERS USING SAME REMOTE SEAL ON THE TWO SIDES

Urea Service Flanged Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
1 ¹ / ₂ in	1.4kPa, 14mbar, 5.6inH ₂ O	0.56kPa, 5.6mbar, 2.24inH ₂ O	1.8kPa, 18mbar, 7.2inH2O
2 ¹ / ₂ in	0.22kPa, 2.2mbar, 0.88inH ₂ O	0.1kPa, 1mbar, 0.4inH2O	0.09kPa, 0.9mbar, 0.36inH2O

BASIC ORDERING INFORMATION model S264P Remote Seal for Urea Service


Select one character or set of characters from each category and specify complete catalog number.




Note 1: Not available with Size/Mounting flange code J Note 2: Not available with Size/Mounting flange code H


S264B Model Button Type Remote Seal (To be used only for gauge pressure)


These remote seals are designed to connect directly to a process pipe via the NPT threaded connection or to match pipe fitting with an interface suitable for the provided mating flange. The button seals, due to their design, are dedicated for measurement with medium/high calibrated span (2 MPa/20 bar/290 psi approx. or greater).




3 1/4in flange extended - type 91











Maximum Working Pressure (20 to 120°C; 68 to 248°F)

Universal-type 90

Types 89, 90 and 92: 42MPa, 420bar, 6090psi

Types 91: 35Mpa, 350bar, 5075psi

Vacuum Service

Full vacuum subject to fill fluid limits.

Refer to table A.

Process Temperature Limits

Same as fill fluid limits. Refer to table A.

Temperature effect

The following table shows the temperature effect for 20K (36°F) change, detailed separately for


- the seal (one element) a)
- b) the capillary per meter
- C) the system (transmitter sensor when combined with a seal of specific size/type)

referred to silicone oil for high temperature filling and Hastelloy C276 diaphragm materials.

Button Type Seal Size	Seal error	1m Capillary Error	System (Sensor) Error
1in	8kPa, 80mbar, 32inH2O	1.8kPa, 18mbar, 72inH ₂ O	3.2kPa, 32mbar, 12.8inH ₂ O

BASIC ORDERING INFORMATION model S264B Button Type Remote Seal

Select one character or set of characters from each category and specify complete catalog number.



Note 1: Only available with Bracket type 89 version and suitable for food application

Hastelloy is a Cabot Corporation trademark

ABB has Sales & Customer Support expertise in over 100 countries worldwide

www.abb.com/instrumentation

The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

Printed in Italy (02.04)

© ABB 2004



ABB Ltd

Howard Road, St. Neots Cambridgeshire, PE19 3EU

Tel: +44(0)1480 475321 Fax: +44(0)1480 217948

ABB Inc.

125 E. County Line Road Warminster, PA 18974 USA

Tel: +1 215 674 6000 Fax: +1 215 674 7183

ABB SACE spa

Business Unit Instrumentation Via Statale 113 22016 Lenno (CO) Italy

6000 Tel: +39 0344 58111 7183 Fax: +39 0344 56278