

Features

- "Shrink-Small" Outline Package
- Voltage-controlled output current source requiring one external set resistor per channel
- Current-controlled output current source
- Rise time = 0.8ns
- Fall time = 0.8ns
- On chip oscillator with frequency and amplitude control by use of external resistors to ground
- Oscillator to 500MHz
- Oscillator to 100mA pk/pk
- Single +5V supply ($\pm 10\%$)
- Disable feature for power-up protection and power savings
- CMOS control signals

Applications

- CD-RW applications
- Writable optical drives
- Laser diode current switching

Ordering Information

Part No	Temp. Range	Package	Outline #
EL6146CU	0°C to +70°C	QSOP-16	MDP0040

General Description


The EL6146C is a four channel laser diode current amplifier that provides controlled current to a grounded laser diode. Channels 2, 3, and 4 must be used as the write channels, with switching speeds of approximately one nanosecond rise/fall time. All four channels are summed together at the I_{OUT} output, allowing the user to create multilevel waveforms in order to optimize laser diode performance. The level of the output current is set by an analog voltage applied to an external resistor which converts the voltage into a current at the I_{IN} pin (virtually ground). The current seen at this pin is then amplified to become a current source at pin I_{OUT} .

An on-chip 500MHz oscillator is provided to allow current modulation when in any mode. This is turned on when the $OSCEN$ pin is held high. Complete control of amplitude and frequency is set by two external resistors connected to ground at pins $RFREQ$ and $RAMP$ (see graphs in this data sheet for further explanation).

Output current pulses are enabled when an 'L' signal is applied to the $OUTEN$ pin. No output current flows when $OUTEN$ is 'H', and additional laser diode protection is provided since the $OUTEN$ input will float high when open. Complete I_{OUT} shutoff is also achieved by holding the $ENABLE$ pin low, which will override all other control pins.

The external resistors allow the user to accurately and independently set each amplifier transconductance by applying a voltage to each resistor, without restriction on the voltage range, thus ensuring broad voltage DAC compatibility. Alternatively, the I_{IN} pin can be biased from a current DAC or other current source.

Connection Diagram



Note: All information contained in this data sheet has been carefully checked and is believed to be accurate as of the date of publication; however, this data sheet cannot be a "controlled document". Current revisions, if any, to these specifications are maintained at the factory and are available upon your request. We recommend checking the revision level before finalization of your design documentation.

© 2001 Elantec Semiconductor, Inc.

December 4, 2001

EL6146C - Product Brief

4-Ch Laser Diode Driver + Oscillator

General Disclaimer

Specifications contained in this data sheet are in effect as of the publication date shown. Elantec, Inc. reserves the right to make changes in the circuitry or specifications contained herein at any time without notice. Elantec, Inc. assumes no responsibility for the use of any circuits described herein and makes no representations that they are free from patent infringement.



Elantec Semiconductor, Inc.

675 Trade Zone Blvd.
Milpitas, CA 95035
Telephone: (408) 945-1323
 (888) ELANTEC
Fax: (408) 945-9305
European Office: +44-118-977-6020
Japan Technical Center: +81-45-682-5820

WARNING - Life Support Policy

Elantec, Inc. products are not authorized for and should not be used within Life Support Systems without the specific written consent of Elantec, Inc. Life Support systems are equipment intended to support or sustain life and whose failure to perform when properly used in accordance with instructions provided can be reasonably expected to result in significant personal injury or death. Users contemplating application of Elantec, Inc. Products in Life Support Systems are requested to contact Elantec, Inc. factory headquarters to establish suitable terms & conditions for these applications. Elantec, Inc.'s warranty is limited to replacement of defective components and does not cover injury to persons or property or other consequential damages.